

## Draining Portable Spas

Your spa is equipped with an external drain. The drain is located outside the spa on the black ABS kick plate. To drain the spa, unscrew the outer cap and attach a garden hose to the drain. Turn the ridged ring that is up against the ABS kick plate counter clockwise (almost half a turn) until it stops. Pull firmly on the hose to activate water flow.

When the spa is done draining, push the drain in and turn clockwise until it stops. Remove the hose and reinstall outer cap.